


# SafeLine FD4-CAN Operating instructions



Displays floor designations, arrows and scrolling messages.





# SafeLine FD4-CAN Operating instructions

## **TECHNICAL DATA**

Power:	19-28 VDC
Size (H x W x D):	61 x 80 x 25 mm
Current consumption, standby: Max output current on each output: Max output current for the card:	120 mA / 24 VDC 200 mA 1 A / 24 VDC
Power input:	19-28 VDC
Input current on each input:	8 mA / 24 VDC
SD-card:	Kingston and Verbatin 1, 2 or 4 GB
Speaker output:	0,6W at 8Ω 0,3W at 16Ω

All output are shortcut protected.

# safeline.eu

5

9

# Installation

Wiring instructions

4


6 7 Wiring instructions for FD4-AX




Settings Programming FD4-AX, Direction of the button



#### WIRING INSTRUCTIONS




LED



Heartbeat Flashing 2Hz

#### WIRING INSTRUCTIONS FOR FD4-AX





#### SETTINGS

General settings are made by CAN-wizard. Settings and audio files can be saved on the micro SD-card.

#### Micro SD-card

The memory card contains the following folders: CFG WAV FIRMWARE

#### CFG

In CFG is where the file CONFIG.FD4 is located. It has all the settings of the unit. If an empty memory card is inserted, the unit will by default create a catalog and write a "CONFIG.FD4-file.\*

#### WAV

In WAV is where any sound files, used by the unit, are located. Audio files have to be in the WAV format (16bit, 16kHz mono), and correspond to the search path given in CAN-wizard.

#### FIRMWARE

When needed updated software can be added here to update the unit.

#### Update of software:

- 1. Disconnect the power to FD4-CAN.
- 2. Insert a micro SD card, that has the new software located in the folder named FIRMWARE for eg. "X:\FIRMWARE\FD4-CAN-03\_1.0.0.bin"
- Press and hold the down-button on the backside of the FD4-CAN, and power up the unit. Hold the down-button until the upper part of the display reads "BLT" and the lower half reads the software version. Then release the down-button. The unit will now start.

\*For transfer of settings between units see chapter "Replacing FD4-CAN".

### PROGRAMMING


Save settings from FD4-CAN on to a micro SD-card

- 1. Disconnect the power to FD4-CAN.
- 2. insert an empty micro SD-card into the unit.
- 3. Power the FD4-CAN. The transfer starts automatically.

Note that sound files cannot be transfered this way, as they never are stored directly onto the FD4-CAN.

#### **Replacing FD4**


- 1. Disconnect the power to new unit.
- 2. Insert the micro SD-card from the old unit into the new unit.
- 3. Press and hold the down-button on the backside of the FD4-CAN, and power up the unit. Hold the button until the upper part of the display reads "CFG" and the lower half reads the software version. Then release the button. The unit will now reboot.



# Configuration

Volume, LED-brightness and node-ID are configured with the buttons on the back of the unit. If no selection has been made after a couple of seconds the unit will leave the "Settings-menu\* and return to normal mode.

Do not change Node-ID! Correct node-ID is set at delivery.




### FD4-AX, DIRECTION OF THE BUTTON

FD4-AX with one button (AX-FD4-VW-B1) is by default delivered with the button directing down. To turn it around, and have the button directing up instead, do the following:

1

Take out the lens/display and the circuite board.



Disassemble the two parts.


KOD

Panne daban


2

112

**3** Disassemble the button.



4 Turn the button around, so that it directs up. Place it back in the circuit borad with an angle, and turn it to its correct position.



**5** Reassemble the components by doing the steps in reverse order (i.e., step 3, step 2 and step 1).

Notes





SafeLine Sweden Antennvägen 10 13548 Tyresö SWEDEN

Tel: +46 (0)8 447 79 32 Fax: +46 (0)8 447 79 31 E-mail: order@safeline.eu



SafeLine-Deutschland Westfalenstraße 22a D-51688 Wipperfürth DEUTSCHLAND

Tel: +49 (0)2267 8 67 96 63 E-mail: order@safeline.eu





SafeLine Denmark Erhvervsvej 19 2600 Glostrup DFNMARK

Tel: +45 44 91 32 72 E-mail: order@safeline.eu




SafeLine Europe Blvd de la Woluwe 42. 1200 Brussels BELGIUM

Tel: +32 (0)2 762 98 10 Fax: +32 (0)2 762 97 10 E-mail: order@safeline.eu



SafeLine Elevator Parts UK 3 Evegate Park Barn Smeeth Ashford Kent TN25 6SX United Kingdom

Tel: +44 (0)1303 81 34 14 Fax: +44 (0)1303 81 45 29 E-mail: order@safeline.uk.com





12